



TABLA DE POTENCIA

MOTORES LISTER - PETTER NUEVOS

MODELO	ARRANQUE/RPM	1500	1800	2000	2500	3000	3600
LV1-01 IND 520	MANIVELA	4.7	5.7	6.4			
LPA2-01	ELECTRICO	6.3	8	9.1	11.5	13.9	
TR1-A01 IND 503	MANIVELA	7.4	9	9.8	11.5		
TR1-A02 PUMP 500	ELETRICO	7.4	9	9.8	11.5		
TR1- A08 TR1STD	ELETRICO		9				
LPW2-A02 OND 510	ELETRICO	9.1	11.4	12.9	15.8	18	
LPW2A27 LPW227	ELETRICO		12.5				
LPW2A910	ELETRICO						20.6
LPWS2A-402 IND 514	ELETRICO	9.9	12.2	13.5	16.3	18	
LPWS2-A408 LPWS2G18	ELETRICO		12.5				
LPW3-A02 IND 511	ELETRICO	13.8	17.2	19.4	23.7	27	
LPW3A27 LPW327	ELETRICO		18.6				
LPW3A910	ELETRICO						31
LPWS3A-402 IND 515	ELETRICO	14.9	18.2	20.4	24.5	26.9	
LPWS3A-408 LPWS3 G18	ELETRICO		18.6				
TR2A01 IND 504	MANIVELA	14.8	17.6	19.4	23.2		
TR2A02 PUMP 501	ELETRICO	14.8	17.6	19.4	23.2		
TR2A08 TR2STD	ELETRICO		17.6				
LPW4-A02 IND 512	ELETRICO	18.2	22.7	25.9	31.6	35.9	
LPW4A27 LPW427	ELETRICO		24.9				
LPW4A910	ELETRICO						41.3
LPWS4A-402 IND 516	ELETRICO	19.7	24.4	27	32.7	35.9	
LPWS4A-408 LPWS4G18	ELETRICO		24.9				
TR3-A01 IND 505	MANIVELA	22.5	27.1	29.8	34.7		
TR3-A02 PUMP 502	ELECTRICO	22.5	27.1	29.8	34.7		
TR3-A08 TR3STD	ELECTRICO		27.1				
LPW4T401 PUMP 509	ELECTRICO/TURBO					50.2	
LPWT4A302 IND 513	ELECTRICO/TURBO					50.2	
LPWT4A81 LPWT4081	ELECTRICO/TURBO		31.9				
LPWST4A408 LPWST4G18	ELECTRICO/TURBO		31.9				
LPWT4A09B LPW9T4ST	ELECTRICO/TURBO		50.25				